# ICE-3103, Microwave Engineering (Smith Chart)



#### **Tanvir Zaman Khan**

Assistant professor

Dept. of Information & Communication Engineering Noakhali Science and Technology University Noakhali-3814, Bangladesh

### We have to find out using Smith chart


- $\stackrel{\checkmark}{a}$ ) Voltage reflection coefficient,  $\Gamma$
- б) Voltage standing-wave ratio, VSWR
- $\mathcal{E}$ ) Finding input impedance,  $\mathbf{Z}_{in}$
- d) Finding load impedance,  $Z_L$
- e) the distances of the voltage maximum and voltage minimum,  $d_{max}$  ,  $d_{min}$  OR  $l_{max}$  ,  $l_{min}$

#### **Set: A1 Question**

A 50- $\Omega$  lossless line is terminated in a load impedance,

 $Z_L = (25+j50)\Omega$ . Use the smith chart to find

- a) voltage reflection coefficient,
- b) the voltage standing-wave ratio,
- c) the input impedance of the line, given the line is  $0.14\lambda$




#### **Solution:**


Normalized load impedance,  $Z_L = \frac{25 \Omega}{50 \Omega} + j \frac{50 \Omega}{50 \Omega} = 0.5 + j1$ 


Ans: Normalized,  $Z_L = 0.5 + j1$ 


- a) $\Gamma$  = 0.62 ∠83°
- b) VSWR = 4.2
- c) Normalized  $Z_{in} = 03 j1.8;$



VSWR = 4.2 Voltage reflection coefficient,  $\Gamma$ = 0.62 $\angle$ 83°







S is numerically equal to the value of  $r_0$  at  $P_{\text{max}}$ , the point at which the SWR circle intersects the real  $\Gamma$  axis to the right of the chart's center.

S= 4.2


At H= 
$$3 - j1.8$$
 $\downarrow$ 
 $\downarrow$ 
 $\downarrow$ 
 $\downarrow$ 
 $\downarrow$ 
 $\downarrow$ 

So the input impedance, 
$$Z_{in}$$
 at H =  $(3-j1.8)Z_0\Omega$   
=  $(3-j1.8)50\Omega$   
=  $(150-j90)\Omega$ 

#### **Set: A2 Question**


A 50- $\Omega$  lossless line is terminated in a load impedance,


- $Z_L = (25+j50)\Omega$ . Use the smith chart to find
- a) voltage reflection coefficient,
- b) the voltage standing-wave ratio,
- c) the input impedance of the line, given the line is  $0.12\lambda$



#### **Solution:**

Normalized load impedance, 
$$Z_L = \frac{25 \Omega}{50 \Omega} + j \frac{50 \Omega}{50 \Omega} = 0.5 + j1$$





S is numerically equal to the value of  $r_0$  at  $P_{\text{max}}$ , the point at which the SWR circle intersects the real  $\Gamma$  axis to the right of the chart's center.


$$S = 4.2$$


At D= 
$$4.2 + j0$$


$$\downarrow \qquad \downarrow$$


$$R \qquad X$$

So the input impedance, 
$$Z_{in}$$
 at D =  $(4.2+j0)Z_0\Omega$   
=  $(4.2+j0)50\Omega$   
=  $210\Omega$ 










#### **Set: B Question**

A 50- $\Omega$  lossless line is terminated in a load impedance,

 $Z_L = (50+j100)\Omega$ . Use the smith chart to find

- a) voltage reflection coefficient,
- b) the voltage standing-wave ratio,
- c) the input impedance of the line, given the line is  $0.15\lambda$




Normalized load impedance, 
$$Z_L = \frac{50 \Omega}{50 \Omega} + j \frac{100 \Omega}{50 \Omega} = 1 + j2$$

#### **Set: C Question**

A lossless transmission line is terminated in a normalized load impedance,  $Z_L = (2-j1)\Omega$ . Use the smith chart to find


- a) voltage reflection coefficient,
- b) the voltage standing-wave ratio,
- c) the input impedance of the line, given the line is  $0.1\lambda$



#### **Set: C Question**


A lossless transmission line is terminated in a normalized load impedance,  $Z_L = (2-j1)\Omega$ . Use the smith chart to find


- a) voltage reflection coefficient,
- b) the voltage standing-wave ratio,
- c) the input impedance of the line, given the line is  $0.1\lambda$



#### Ans:


- a) voltage reflection coefficient=  $0.45 \angle 26.6^{\circ}$
- b) the voltage satanding-wave ratio= 2.65
- c) the input impedance of the line, given the line is  $0.1\lambda$ , = 0.6 j0.66






### Finding Load Impedance, $Z_L$

**Set: D Question** 



### Finding Load Impedance, $Z_L$

**Set: D Question** 




#### **Solution:**

Given:


$$Z_{in}$$
= (100 – j 100)  $\Omega$ 

So, Normalized input impedance, 
$$Z_{in}=\frac{100~\Omega}{50~\Omega}-\mathrm{j}\,\frac{100~\Omega}{50~\Omega}$$
 =  $2-j2$ 

Ans: 
$$Z_L = (0.35 + j0.55) Z_0 \Omega$$




#### **Maxima and Minima**



#### Maxima and Minima

#### **Practice:**

Use the smith chart to find the distances of the first voltage maximum and first voltage minimum from the load



#### Ans:

first voltage maximum=  $0.037 \lambda$  first voltage minimum=  $0.287 \lambda$ 





Figure 2-28: Point A represents a normalized load with  $z_L = 2 + j1$ . The standing wave ratio is S = 2.6 (at  $P_{\text{max}}$ ), the distance between the load and the first voltage maximum is  $d_{\text{max}} = (0.25 - 0.213)\lambda = 0.037\lambda$ , and the distance between the load and the first voltage minimum is  $d_{\text{min}} = (0.037 + 0.25)\lambda = 0.287\lambda$ .

#### **Practice:**

A 50- $\Omega$  lossless line is terminated in a load  $Z_L = (25+j50)\Omega$ .

Use the smith chart to find

- a) voltage reflection coefficient,
- b) the voltage standing-wave ratio,
- c) the distances of the first voltage maximum and first voltage minimum from the load,
- d) the input impedance of the line, given the line is  $3.3\lambda$




#### **Practice:**

A 50- $\Omega$  lossless line is terminated in a load  $Z_L = (25+j50)\Omega$ .

Use the smith chart to find

- a) voltage reflection coefficient,
- b) the voltage standing-wave ratio,
- c) the distances of the first voltage maximum and first voltage minimum from the load,
- d) the input impedance of the line, given the line is  $3.3\lambda$




Ans:  $Z_L = 0.5 + j1$ 

- a)  $\Gamma = 0.62 \angle 83^{\circ}$
- b) VSWR = 4.26
- c)  $d_{max} = 0.115 \lambda$ ,  $d_{min} = 0.365 \lambda$
- d) Normalized  $Z_{in} = 0.28 + j0.40$ ;  $Z_{in} = (14-j20)\Omega$

#### **Practice: Solution**


A 50- $\Omega$  lossless transmission line of length 3.3 $\lambda$  is terminated by a load impedance  $Z_L = (25 + j50) \Omega$ . Use the Smith



#### **Smith Chart slotted line example:**

#### Given:

 $Z_0$  = 50  $\Omega$ , SWR = 3, first voltage min,  $d_{min}$  is 5 cm from load and distance between adjacent minima,  $\frac{\lambda}{2}$  = 20 cm. Find load impedance  $Z_L$ 



#### Solution:

Find 
$$d_{min}$$
 in wavelength format.  $d_{min} = \frac{d_{min} \ value \ in \ cm}{\lambda \ value \ in \ cm} = \frac{5 \ cm}{40 \ cm} = 0.125 \ \lambda$ 

#### Smith Chart slotted line example.

#### Given:

 $Z_0$  = 50  $\Omega$ , SWR = 3, first voltage min,  $d_{min}$  is 5 cm from load and distance between adjacent minima,  $\frac{\lambda}{2}$  = 20 cm. Find load

impedance  $Z_L$   $z_L = ?$ 

#### Solution:


Find 
$$d_{min}$$
 in wavelength format.  $d_{min} = \frac{d_{min} \ value \ in \ cm}{\lambda \ value \ in \ cm} = \frac{5 \ cm}{40 \ cm} = 0.125 \ \lambda$ 

If  $\lambda$  is given in 0.6m then it should be converted into cm, so  $\lambda$ = 60 cm


$$d_{min} = \frac{d_{min} \ value \ in \ cm}{\lambda \ value \ in \ cm} = \frac{14.2 \ cm}{40 \ cm} = 0.355 \ \lambda$$

$$d_{min} = \frac{d_{min} \ value \ in \ cm}{\lambda \ value \ in \ cm} = \frac{12 \ cm}{60 \ cm} = 0.2 \ \lambda$$

#### Smith Chart slotted line example.



## Determination of Unknown Load Impedance from Standing Wave Data Given Zo = 50-2 SWR = 3.0 $\lambda/2 = 20 \text{ cm}$ dmin = 14.2 cm = 0.355 ) Find ZR.



 $\overline{Z}_{R} = 50(0.75 + j0.97) = (37.5 + j48.5) \Omega$